



QUALITROL®

Nomad-Touch™

Portable Fiber Optic Thermometer Instrument

**1-Channel System
With QLink Software**

Proprietary notice:

Details of design and engineering are the exclusive property of **Neoptix Canada LP** (Neoptix) and are strictly confidential. The information given herein is subject to change, at any time and without notice.

All rights are reserved. The information in this document may not be reproduced or passed on in any manner without prior written consent of Neoptix.

Neoptix shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material.

All trademarks are the property of their respective owners.

Part number: G1050R04 (February 2017)

TABLE OF CONTENTS

1	END USER LICENSE & SOFTWARE WARRANTY AGREEMENT	4
1.1	NEOPTIX NOMAD-TOUCH AND PROBE WARRANTY NOTICE	7
2	INTRODUCTION.....	8
2.1	NOMAD-TOUCH PRODUCT SPECIFICATIONS	9
2.2	CALIBRATION	10
2.3	TRANSFORMER APPLICATIONS.....	10
3	UNPACKING	11
4	QUICK INTRODUCTION.....	12
4.1	MAKING YOUR FIRST MEASUREMENTS.....	12
4.1.1	<i>Installing the USB serial driver.....</i>	<i>12</i>
4.1.2	<i>Charging the internal battery.....</i>	<i>14</i>
4.1.3	<i>Using the Nomad-Touch.....</i>	<i>14</i>
5	NOMAD™ THERMOMETER HARDWARE REFERENCE	15
5.1	DISPLAY DESCRIPTION	15
5.2	TOUCH SCREEN OPERATION	15
5.3	THE SETUP MENU	16
5.4	THE ACQUISITION MENU	17
5.5	THE LOGGING MENU	17
5.6	PROBE CONNECTOR.....	18
6	USB COMMUNICATION DESCRIPTION (SERIAL PORT).....	19
6.1	RESTRICTIONS ON SERIAL PORT USE	19
6.2	USING HYPERTERMINAL IN WINDOWS	19
6.3	SERIAL HELP MENU	20
6.4	DETAILED DESCRIPTION OF USB SERIAL COMMANDS	21
6.5	INTERPRETATION OF “Y” COMMAND RESULTS	24
6.6	TYPICAL TEMPERATURE READING SEQUENCE.....	24
7	ERROR CODES.....	25
8	QLINK SOFTWARE DESCRIPTION	26
8.1	INSTALLATION AND INITIAL OPERATION	26
8.2	WHAT IS NEW IN QLINK.....	28
8.3	OVERVIEW OF QLINK	28
8.4	FIRMWARE UPGRADE PROCEDURE	30
8.4.1	<i>Upgrade Procedure, with Serial Port.....</i>	<i>30</i>
8.5	ACQUIRE AND DISPLAY TEMPERATURE DATA	31
8.6	LOGGING DATA TO A FILE	32
8.7	CONFIGURATION TOOL	33
8.7.1	<i>Configuration of Snaplog Prefixes.....</i>	<i>34</i>
8.7.2	<i>Optical Channel Setting.....</i>	<i>35</i>
8.7.3	<i>Offline Configuration Tool.....</i>	<i>35</i>
8.7.4	<i>Download Files Tool</i>	<i>36</i>
8.8	UPLOAD FILES TOOL	37
8.9	SIGNAL QUALITY INFORMATION	38
8.10	WORKING ON CONFIGURATION FILES, WITH NO LIVE INSTRUMENT	38
8.11	TROUBLESHOOTING	39
8.11.1	<i>An example of status file.....</i>	<i>39</i>
9	USING TEMPERATURE PROBES.....	41

9.1	CAUTION	41
9.2	DESCRIPTION.....	41
9.3	WARNING	42
9.4	WORKING WITH CRYOGENIC PROBES	42
10	INDEX	43

Warning

Permanent damage may be done to the thermometer if the power supply connections are not done correctly. Only approved 5 VDC USB power supply modules should be used to operate this *Nomad-Touch*. 1 ampere power supplies are recommended; one such power supply is included with your new unit.

This product does not contain any user-serviceable parts. Although the battery case is user accessible, the battery itself is not user replaceable. Opening this precision instrument will void its warranty and may disturb its factory calibration. Always seek servicing from an authorized Neoptix service depot.

To assure cleanliness of the optical connector, keep the protection cap on unused connector at all time.

Fiber optic probes and extension cables are fragile, and will break if the bending radius becomes less than ~1 cm, even temporarily. Probe and extension cable breakages are not covered under the standard Neoptix warranty. Do not bend the last 1 cm of the probes!

The Neoptix Nomad products are CE marking certified.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

1 END USER LICENSE & SOFTWARE WARRANTY AGREEMENT

PLEASE READ THIS SOFTWARE LICENSE CAREFULLY BEFORE DOWNLOADING, INSTALLING OR USING ANY QUALITROL OR QUALITROL-SUPPLIED SOFTWARE. BY DOWNLOADING OR INSTALLING THE SOFTWARE, OR USING THE EQUIPMENT THAT CONTAINS THIS SOFTWARE, YOU ARE CONSENTING TO BE BOUND BY THIS LICENSE.

The following terms govern your use of the Software except to the extent a particular program (a) is the subject of a separate written agreement with Qualitrol or (b) includes a separate "clickwrap" license agreement as part of the installation and/or download process. To the extent of a conflict between the provisions of the foregoing documents, the order of precedence shall be (1) the written agreement, (2) the clickwrap agreement, and (3) this Software License.

License. Subject to the terms and conditions of and except as otherwise provided in this Agreement, Qualitrol Systems, Inc. or the Qualitrol Systems, Inc. subsidiary licensing the Software, if sale is not directly by Qualitrol Systems, Inc. ("Qualitrol"), and its suppliers grant to Customer ("Customer") a nonexclusive and non-transferable license to use the specific Qualitrol program modules, feature set(s) or feature(s) for which Customer has paid the required license fees (the "Software"), in object code form only. In addition, the foregoing license shall also be subject to the following limitations, as applicable:

- Unless otherwise expressly provided in the documentation, Customer shall use the Software solely as embedded in, for execution on, or (where the applicable documentation permits installation on non-Qualitrol equipment) for communication with Qualitrol equipment owned or leased by Customer
- Customer's use of the Software shall be limited to use on a single hardware chassis, on a single central processing unit, as applicable, or use on such greater number of chassis or central processing units as Customer may have paid Qualitrol the required license fee; and
- Customer's use of the Software shall also be limited, as applicable and set forth in Customer's purchase order or in Qualitrol product catalog, user documentation, or web site, to a maximum number of (a) seats (i.e. users with access to the installed Software), (b) concurrent users, sessions, ports, and/or issued and outstanding IP addresses, and/or (c) central processing unit cycles or instructions per second. Customer's use of the Software shall also be limited by any other restrictions set forth in Customer's purchase order or in Qualitrol product catalog, user documentation or web site for the Software.

NOTE: For evaluation or beta copies for which Qualitrol does not charge a license fee, the above requirement to pay a license fee does not apply.

General Limitations. Except as otherwise expressly provided under this Agreement, Customer shall have no right and Customer specifically agrees not to:

- (i) transfer, assign or sublicense its license rights to any other person, or use the Software on unauthorized or second-hand Qualitrol equipment, and any such attempted transfer, assignment or sublicense shall be void;
- (ii) make error corrections to or otherwise modify or adapt the Software or create derivative works based upon the Software, or to permit third parties to do the same; or (iii) decompile, decrypt, reverse engineer, disassemble or otherwise reduce the Software to human readable form to gain access to trade secrets or confidential information in the Software. To the extent required by law, at Customer's request, Qualitrol shall provide Customer with the interface information needed to achieve interoperability between the Software and another independently created

program, on payment of Qualitrol applicable fee. Customer shall observe strict obligations of confidentiality with respect to such information.

Upgrades and Additional Copies. For purposes of this Agreement, "Software" shall include (and the terms and conditions of this Agreement shall apply to) any upgrades, updates, bug fixes or modified versions (collectively, "Upgrades") or backup copies of the Software licensed or provided to Customer by Qualitrol or an authorized distributor for which Customer has paid the applicable license fees.

NOTWITHSTANDING ANY OTHER PROVISION OF THIS AGREEMENT: (1) CUSTOMER HAS NO LICENSE OR RIGHT TO USE ANY SUCH ADDITIONAL COPIES OR UPGRADES UNLESS CUSTOMER, AT THE TIME OF ACQUIRING SUCH COPY OR UPGRADE, ALREADY HOLDS A VALID LICENSE TO THE ORIGINAL SOFTWARE AND HAS PAID THE APPLICABLE FEE FOR THE UPGRADE; (2) USE OF UPGRADES IS LIMITED TO QUALITROL EQUIPMENT FOR WHICH CUSTOMER IS THE ORIGINAL END USER PURCHASER OR LESSEE OR WHO OTHERWISE HOLDS A VALID LICENSE TO USE THE SOFTWARE WHICH IS BEING UPGRADED; AND (3) USE OF ADDITIONAL COPIES IS LIMITED TO BACKUP PURPOSES ONLY.

Proprietary Notices. Customer agrees to maintain and reproduce all copyright and other proprietary notices on all copies, in any form, of the Software in the same form and manner that such copyright and other proprietary notices are included on the Software. Except as expressly authorized in this Agreement, Customer shall not make any copies or duplicates or any Software without the prior written permission of Qualitrol. Customer may make such backup copies of the Software as may be necessary for Customer's lawful use, provided Customer affixes to such copies all copyright, confidentiality, and proprietary notices that appear on the original.

Protection of Information. Customer agrees that aspects of the Software and associated documentation, including the specific design and structure of individual programs, constitute trade secrets and/or copyrighted material of Qualitrol. Customer shall not disclose, provide, or otherwise make available such trade secrets or copyrighted material in any form to any third party without the prior written consent of Qualitrol. Customer shall implement reasonable security measures to protect such trade secrets and copyrighted material. Title to Software and documentation shall remain solely with Qualitrol.

Term and Termination. This License is effective until terminated. Customer may terminate this License at any time by destroying all copies of Software including any documentation. Customer's rights under this License will terminate immediately without notice from Qualitrol if Customer fails to comply with any provision of this License. Upon termination, Customer must destroy all copies of Software in its possession or control.

Customer Records. Customer grants to Qualitrol and its independent accountants the right to examine Customer's books, records and accounts during Customer's normal business hours to verify compliance with this Agreement. In the event such audit discloses non-compliance with this Agreement, Customer shall promptly pay to Qualitrol the appropriate licensee fees.

Export. Software, including technical data, may be subject to U.S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries. Customer agrees to comply strictly with all such regulations and acknowledges that it has the responsibility to obtain licenses to export, re-export, or import Software.

U.S. Government End Users. The Software and associated software documentation qualify as "commercial items," as that term is defined at 48 C.F.R. 2.101, consisting of "commercial computer software" and "commercial computer software documentation" as such terms are used in 48 C.F.R. 12.212. Consistent with 48 C.F.R.12.212 and 48 C.F.R. 227.7202-1 through 227.7202-4, Licensee will provide to Government end user, or, if this Agreement is direct Government end user will acquire, the Software and software documentation with only those rights set forth herein that apply to nongovernmental customers. Use of this Software and software documentation constitutes agreement by the government entity that the computer software and computer software documentation is commercial, and constitutes acceptance of the rights and restrictions herein.

Limited Warranty. Qualitrol Systems, Inc. or the Qualitrol Systems, Inc. subsidiary licensing the Software, if sale is not directly by Qualitrol Systems, Inc. ("Qualitrol") warrants that commencing from the date of delivery to Customer and continuing for a period of the longer of (a) ninety (90) days or (b) the period set forth in the Warranty Card accompanying the Product (if any): (a) the media on which the Software is furnished will be free of defects in materials and workmanship under normal use; and (b) the Software substantially conforms to its published specifications. The date of shipment of a Product by Qualitrol is set forth on the packaging material in which the Product is shipped. Except for the foregoing, the Software is provided "AS IS". This limited warranty extends only to the Customer who is the original licensee. Customer's sole and exclusive remedy and the entire liability of Qualitrol and its suppliers under this limited warranty will be, at Qualitrol or its service center's option, repair, replacement, or refund of the Software if reported (or, upon request, returned) to the party supplying the Software to Customer, if different than Qualitrol. In no event does Qualitrol warrant that the Software is error free or that Customer will be able to operate the Software without problems or interruptions. In addition, due to the continual development of new techniques for intruding upon and attacking networks, Qualitrol does not warrant that the Software or any equipment, system or network on which the Software is used will be free of vulnerability to intrusion or attack.

Restrictions. This warranty does not apply if the Product (a) has been altered, except by Qualitrol, (b) has not been installed, operated, repaired, or maintained in accordance with instructions supplied by Qualitrol, (c) has been subjected to abnormal physical or electrical stress, misuse, negligence, or accident; or (d) is licensed, for beta, evaluation, testing or demonstration purposes for which Qualitrol does not receive a payment of purchase price or license fee.

DISCLAIMER OF WARRANTY. EXCEPT AS SPECIFIED IN THIS WARRANTY, ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS, AND WARRANTIES INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT, SATISFACTORY QUALITY OR ARISING FROM A COURSE OF DEALING, LAW, USAGE, OR TRADE PRACTICE, ARE HEREBY EXCLUDED TO THE EXTENT ALLOWED BY APPLICABLE LAW. TO THE EXTENT AN IMPLIED WARRANTY CANNOT BE EXCLUDED, SUCH WARRANTY IS LIMITED IN DURATION TO THE WARRANTY PERIOD. BECAUSE SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION.

This disclaimer and exclusion shall apply even if the express warranty set forth above fails of its essential purpose.

Disclaimer of Liabilities. IN NO EVENT WILL QUALITROL OR ITS SUPPLIERS BE LIABLE FOR ANY LOST REVENUE, PROFIT, OR DATA, OR FOR SPECIAL, INDIRECT, CONSEQUENTIAL, INCIDENTAL, OR PUNITIVE DAMAGES HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY ARISING OUT OF THE USE OF OR INABILITY TO USE SOFTWARE EVEN IF QUALITROL OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

In no event shall Qualitrol's or its suppliers' liability to Customer, whether in contract, tort (including negligence), or otherwise, exceed the price paid by Customer. The foregoing limitations shall apply even if the above-stated warranty fails of its essential purpose.

BECAUSE SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATION OR EXCLUSION OF CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

The Warranty and the Software License shall be governed by and construed in accordance with the laws of the State of New York, without reference to principles of conflict of laws, provided that for Customers located in a member state of the European Union, Norway or Switzerland, English law shall apply. The United Nations Convention on the International Sale of Goods shall not apply. If any portion hereof is found to be void or unenforceable, the remaining provisions of the Warranty and the Software License shall remain in full force and effect. Except as expressly provided herein, the Software License constitutes the entire agreement between the parties with respect to the license of the Software and supersedes any conflicting or additional terms contained in the purchase order.

If Customer has entered into a contract directly with Qualitrol for supply of the Products subject to this warranty, the terms of that contract shall supersede any terms of this Warranty or the Warranty Card, or the Software License, which are inconsistent with that contract. Customer acknowledges that the Internet URL address and the web pages referred to in this document may be updated by Qualitrol from time to time and the version in effect at the date of delivery of the Products to the Customer shall apply.

1.1 Neoptix Nomad-Touch and Probe Warranty Notice

Your Nomad-Touch unit is guaranteed (Parts and Workmanship) for one full year from the date of purchase. Upon written notification of any defect, Neoptix will either repair or replace any faulty product or components thereof. A Return Authorization Number (RMA) must be obtained from Neoptix Canada LP or authorized distributor prior to any merchandise return.

Due to the unique nature of the fiber optic probes that are used with this Neoptix Conditioner system, probes and extension cables are not guaranteed.

When using any electrical appliance, basic safety precautions should be followed, including the following:

- Do not operate in wet / damp environments
- Do not operate in explosive atmospheres
- Keep product surface dry and clean.

Always make sure all electrical installations are made in accordance with local authorities' regulations and laws.

2 INTRODUCTION

Congratulations on the purchase of your Nomad-Touch™ thermometer product! Your new temperature-sensing instrument will soon allow you to take full advantage of the benefits inherent to fiber optic sensing technology. It offers accurate and reliable temperature measurements, combined with extraordinary insensitivity to EMI/RFI, high voltage insulation and disturbance free sensing due to the non-electrical nature of the sensor element used.

Not only does the Nomad family of products gives access to reliable measurements, but it also offers a simple user interface that makes the technology easy to use. Moreover, no special calibration is required when changing the fiber optic sensor elements.

The thermometer is packaged in a small hand-held package, which is ideally suited for portable applications. This model does not feature an analog output option nor a through RS485 serial port; the Neoptix model T/Guard-405 is recommended when these options are required.

The standard configuration is offered with a USB interface. In addition, a large color touch LCD graphical display (QVGA, 320 x 240 pixels) makes it easy to see the temperature, either in Celsius (°C) or in Fahrenheit (°F), even in dark areas (by activating the back light); menu selections are all made by touching icons on the display; these standard features are great for laboratory and field applications. Furthermore, a convenient data-logging feature is included; logging is done directly to an internal 32 MB memory, allowing saving almost 400,000 temperature events.

This newly designed thermometer includes the latest developments in fiber optic temperature measurement technologies. Most types of GaAs-based probes now available on the market are supported, even probes manufactured by Neoptix' competitors. It will also interface with and read marginal probes, or probes with dirty connectors, and so forth. It will give you years of excellent service.

The QLink software package is an excellent complement to your thermometer.




2.1 Nomad-Touch product specifications


Resolution	0.1 °C
Accuracy	± 1 °C
Calibrated Temperature Range	-45° to 200 °C
Usable Temperature Range	-80° to 250 °C
Number of channel	1
Probe length	1 to 500 meters (and more)
Sensor	Dielectric epoxy or silicone tipped optical fiber probes Any T1 or T2 Neoptix probes Second calibration supports older Nortech Fibronic Inc. probes
Response time	Typically 0.2 to 0.5 second (Probe and setting configuration dependent) Sampling rate is ~ 5 Hz
Probe compatibility	All Neoptix probes (T1 and T2) Nortech Fibronic Inc. probes (with built-in special calibration)
Unit	User selection of °C or °F
Data logging feature	Internal 32 MB memory for readings and probe performance data
Operating temperature	-20 ° to 50 °C, non-condensing
Storage temperature	-30 ° to 50 °C Warning: the battery will degrade quickly at high temperature
Local display	Display of temperature readings as well as various user information Graphical resolution: QVGA 240 x 320 pixels, color Touch resistive plane
Power	5 VDC (USB port), ~350 mA
Upgradability	Main firmware: through USB port Display: through concealed USB port in battery compartment
Internal batteries	Lithium-Ion rechargeable battery Battery is <i>not</i> user replaceable Autonomy of up to 5 hours
Size	170L x 118W x 37D mm
Weight	0.7 kg
Standard interface	USB connector (type B)

All technical specifications are subject to change without notice.


The following figure gives a description of the various probe configurations that are optionally available from Neoptix.




General Purpose Probe T2:



ST-ST Coupling:



ST-ST Extension Cable



2.2 Calibration

Your T/Guard thermometer comes factory-calibrated. Experience has shown that re-calibration is not required over the whole product life; however, if your ISO rules state that an annual re-calibration is required, then it is your responsibility to comply with those rules. For laboratory applications, a new calibration is standard every 12 months or whenever performance verification indicates that calibration is necessary; NIST traceable calibration certificates are available. All calibrations are performed at the factory. Contact your Neoptix Representative for further information.

2.3 Transformer applications

One of the main applications for the T/Guard product is monitoring temperature of hot spots in power transformers. Since its inception, Neoptix has developed expertise in this application, and is considered as a world leader in this field. Sister products of the T/Guard, the T/Guard-2B, T/Guard-Link, T/Guard-408, are ideal for the power transformer industry. Neoptix publishes a User Guide, called "Probe Installation Guide", totally dedicated to the power transformer industry; do not hesitate to ask for your copy if you are working in this field (Neoptix document # G1009).

3 UNPACKING

Before using your Nomad thermometer, check the box content to be sure all items have been included. Your package should normally contain:

- Nomad-Touch signal conditioner unit
- USB power supply module (universal input: 100-240 VAC, 50/60 Hz; output: 5 VDC 1 A).
- Short extension cord and mating sleeve (should be used to minimize damages to the connector at the Nomad interface)
- 1 m USB cable
- Neoptix QLink software package, on the DVD
- User manual (this manual) (paper copy not included, supplied as a PDF document on the DVD)
- Calibration Certificate.

Options:

- Fiber optic temperature sensor probes
- Fiber optic extension cables
- Fiber optic couplings and feedthroughs
- Carrying case, for Nomad and accessories.


Make sure all listed items have been received and are in good condition. Note any evidence of rough handling in transit; immediately report any damage to the shipping agent. Should a part be missing or damaged, please contact your distributor immediately. Returns must be made with the original packaging, accompanied by an authorization number (RMA). Your distributor will provide you with information concerning the return of merchandise.

The carrier will not honour damage claims unless all shipping material is saved for inspection. After examining and removing contents, save packing material and carton in the event reshipment becomes necessary.

4 QUICK INTRODUCTION

The best way to familiarize yourself with your new Nomad is, of course, to use it! This chapter shows you to prepare your unit and do some initial measurements. The detailed instructions are given in the next Chapter.

Your new Nomad comes calibrated and ready to use. This figure shows the main view of the Nomad, along with the top and bottom views.




4.1 Making your first measurements

4.1.1 Installing the USB serial driver


WARNING: It is highly recommended to install the USB driver in your PC **BEFORE** you connect the Nomad-Touch to it. You will find the driver on the Internet and on the DVD that comes with this Nomad. This section explains how to install this driver.

You will find the driver on the DVD; you can also download it from the Internet from this site: <http://www.ftdichip.com/Drivers/CDM/CDM%20v2.10.00%20WHQL%20Certified.exe>. The procedure is as follows (assuming the download is done on the Internet):

- Save the file on your C: hard disk, or on a local disk of your choice.



- Click the file name (in Windows Explorer) to execute it.



- The installation will proceed, first with this window, click Extract:



- Then the installation proper will proceed, click Next:



- Finally, you get this information. Click Finish.



You can now connect your Nomad-Touch to this PC. In case of problems, Section 8.11 includes some hints about possible solutions to common problems.

4.1.2 Charging the internal battery

Before using the unit, you will need to connect it to a suitable USB power source; with the included 1 A power module, you should wait about 5 hours to fully charge the internal battery.

If you connect it to a PC USB port, a full charge may be as long as 10 to 15 hours. It will take longer if the unit is on during the charging process and also much longer if the FTDI serial driver has not been installed on that PC (see previous section on how to install the serial driver).

4.1.3 Using the Nomad-Touch

To make your first temperature measurement, do as follows:

- Remove the dust cap on the optical connector of the Nomad (located on the top of the Nomad).
- Remove the dust cap on the probe connector.
- Insert the connector from your probe into the sensor connector of the Nomad. Make sure the two mating parts are properly aligned and twist the connector clockwise to fasten it securely. Note: Do not apply force on this connector!
- Turn your Nomad on by pressing  for at least one second. After a few seconds, a “splash” screen with the some software version information will be displayed. Then the temperature is immediately displayed, along with the date and time, and probe performance data. This is shown here:



- Place the sensor tip on a warmer surface (such as your hand): you can observe the temperature variation on the display.
- You can power it down by pressing again this key, for a minimum of one second: .


5 NOMAD™ THERMOMETER HARDWARE REFERENCE

5.1 Display description

The display is organized in 5 logical horizontal regions:

- The top portion gives general information to the user about the unit current status, such as battery condition, USB connection status, and time and date.
- Then you have the temperature number, in Celsius or Fahrenheit.
- Immediately below the temperature, you get some information about your probe optical performance. See section 6.5 for a discussion on probe performance.
- The next portion gives information about temperature logging. Logging can occur in two ways: 1) snap logging which is manual, and 2) automated logging done at regular time interval.
- The bottom portion shows four icons that can be invoked to further configure your thermometer, or to give you access to more advanced menus.

The display is illustrated below:



The Nomad-Touch front panel includes an on/off button, with a red LED on indicator. Furthermore, a status USB LED gives the following information:

- Off: The Nomad is not connected to any USB supply.
- Yellow-green: The unit is connected to a USB 5 VDC power supply, and the battery is being charged.
- Green: The unit is connected to a USB power supply, and the battery is fully charged.

Note: This LED gives a status on the 5 VDC power supply. It does not give a status about any software link to a PC.

5.2 Touch screen operation

The touch screen is very simple to use. The touch technology used for the Nomad-Touch is resistive touch layer. This means that the menu selection can be done by anything that can apply a small pressure on the display surface; this pressure can be applied by naked fingers, gloves, stilettos, etc. You can select the "Power" icon to change the operation of the display, such as brightness and backlight. The "Power" icon gives you the following display variations:




From this screen, you can optimize the battery use parameters (when connected and not connected to USB).
Note: “-” means “never”.

- DIMMED SCREEN: Number of minutes after which the screen will be dimmed.
- STANDBY: Number of minutes after which the screen is turned off.
- SHUT DOWN: Number of minutes after which the Nomad-Touch is turned off.

Each sub-menu has a “help” button that gives more information about the various parameters.

5.3 The setup menu

This menu allows for setting the date and time. It can also be invoked to reset all parameters to the factory defaults, as well as clearing the temperature logging memory.



The details of these parameters are here:

- DATE: Enter today's date.
- TIME: Enter current time. Time can be entered and displayed in 12h or 24h format.
- RESET: Factory defaults and Log memory. This action requires a confirmation.
 - o Press the appropriate area on the screen for a minimum of 1 second, and then a message requesting confirmation will appear.
- RESET: Log memory. This action requires a confirmation.
 - o Press the appropriate area on the screen for a minim of 1 second, and then a message requesting confirmation will appear. This delete operation may take a few minutes.
 - o Log temperature files can also be erased using the QLink tool; see QLink information below.

5.4 The acquisition menu

This menu can be selected by pressing the “Acquisition” icon from the main window. The following screen then appears:



Here you have access to the following parameters:

- UNIT: Celsius or Fahrenheit
- WTUNE: It is suggested to turn on this parameter, unless very fast measurements are to be done. This makes the system more sensitive, at the cost of speed.
- GSKIP: A value of 5 is suggested. This represents the number of readings the thermometer will do before abdicating.
- PROBE TYPE: Select Nortech Fibronic Inc. to read old probes.
- OFFSET: This allows modifying the calibration by adding this offset to the read value. The offset must be within ± 20 degrees.



Information: If you select Nortech Fibronic probes or an offset, there will be a note informing you in the main window.

5.5 The logging menu

Your Nomad-Touch includes a very useful temperature-logging feature. The logged data is internally stored as binary files. The files consist of up to 65,000 lines of data, each line representing the temperature for the single channel along with a date-time stamp, the probe name (prefix and sequential number 00 to 99), and probe optical performance data. This means that the 32 MB total space can accommodate a total of 6 such files. This represents a grand total of 390,000 lines, or about 7.5 years of data if the sampling rate is 1 sample per 10 minutes. Once all 6 files have been filled up, the oldest file is deleted without any warning and replaced by a new one. These 6 files can be downloaded using the QLink software.


The logging files can be deleted via

The logging parameters can be controlled from the 2 windows shown below; the one on the left illustrates the case where the “snap” mode is active, while the one on the right illustrates the logging done automatically at regular time intervals.



The parameters available from these screens are:

- **MODE:** Auto means that logging will be done at fixed time intervals. Snap means “manual” logging; a sample is saved when the SNAP (on the main screen) button is pressed.
- **RATE:** Logging rate from adjustable from 1 second to 61 minutes.
- **SNAP DEFAULT PREFIX NAME:** Prefix that will be used to identify probes when testing in snap mode. This prefix will be followed by 2 numbers that would normally identify the probe then currently tested. QLink allows you to manage the prefixes; 15 prefixes are supported.)
 - o The prefix name and the 2-digit number are saved with the logged temperature data when the snap button is pressed.
- **OPEN LOG VIEWER:** Allows you to review the temperature data logged in internal memory. Data can be selected by 1) the cursor, for coarse selection; and 2) the left and right arrows, for fine selection. The log viewer screen looks like this:



Note that the cursor () is not displayed when the log memory contains less than 11 entries.

File name conventions:

- 1- The current log file is always named temperatures.tem
- 2- When the current file is full, it is archived with the same name but by adding to it a prefix that corresponds to the date and time at the time of closing this file.

5.6 Probe connector

This ST connector mates to a Neoptix temperature probe. It will also work fine with older Nortech Fibronic Inc. probes, as long as the appropriate calibration selection is made.

6 USB COMMUNICATION DESCRIPTION (SERIAL PORT)

You can communicate with your *Nomad-Touch* thermometer via the standard USB link. This first protocol implementation on this Nomad is an emulation of a serial port.

VERY IMPORTANT: Before you connect it for the first time to a PC, you must install a driver in this PC. The procedure to do this is outlined in Section 4.1.1.

Recommendation: The use of QLink software is highly recommended as an alternative to the serial command protocol described in this chapter; for more information on QLink, see chapter 8.

Your Nomad-Touch should now be ready for use with software's such as:

- QLink
- HyperTerminal¹, or Tera-Term; this is described below..

Take note of the serial port information given when the driver is installed (COM8 in the above example); you may need this information to connect to the above mentioned software packages.

6.1 Restrictions on Serial Port Use

The use of serial port may occasionally cause some problems. Some of them are:



- When you connect multiple *Nomad-Touch*'s to your PC, the serial port Windows logic will always generate a different COM port number, a new one every time you connect a new instrument. After a while, this may result in a COM port that has an assigned number which is very high (for example, QLink requires that the port number be 32 or less). If this is the case, you will need to overwrite older COM ports that you do not use anymore; a COM port number can be reassigned in Device Manager.
- If your PC does not find a driver automatically, you should use the one that is on the DVD included with the instrument.

6.2 Using HyperTerminal in Windows

Hyper Terminal is a standard Windows program that can be easily used to exercise your Nomad thermometer. To use Hyper Terminal, you first set its properties as follows:

- 1- In the "Connection Description" window, enter a name that suits you, such as "Neoptix-Nomad". Click OK.
- 2- In the next window, "Connect To", select COM1 (or another COM port, if you are planning to use another port than COM1) in the box called "Connect using". Click OK.
- 3- Then the COM1 Properties window will come up. As indicated above and as shown in the figure at right, set the port parameters to 9600 Baud, 1 Stop-Bit and No-Parity. Click OK.
- 4- You are ready to go. Type "h  " to test your setup (see below). Warning: the characters that you enter are not echoed to you!

¹ Vista, Win-7, -8 and -10 Windows users: HyperTerminal is not included with Vista and subsequent Windows versions. However, an equivalent program (HTPE) can be downloaded (for a fee) at the following website: <http://www.hilgraeve.com/htpe/download.html>. Tera Term (freeware) has also given good results; see <http://tssh2.sourceforge.jp/>.



6.3 Serial help menu

The following is the menu as displayed by the instrument when sending the “h” command. Note that the USB interface can also be used to upgrade the thermometer controlling firmware, without opening the thermometer case. Instructions to perform an upgrade are normally sent with the upgrade program; a PC compatible computer will be required to perform such upgrade.

Nomad-1	Description
baud :nnnn	Set baud rate to 'nnnn' bit per second, valid rates are: 9600, 115200 or 921000 (remember to reconnect)
batt?	Battery information
c:xxxxx	Clean up (delete) log file xxxxx (use command “l” to list files)
f[j]	Set point adjustment on channel to [j]
format	Erase all log files
gskip[i]	Skip up to i (0 to 9) marginal read cycles
h	Help menu (this screen)
i	Get factory and status information
l	List log files
logging[i]	Logging+ to enable logging, logging- to disable. Note: to use snap, logging- must be selected
n+[i]	Select calibration type (n+e for Neoptix, n+o for Nortech-F)
rd	Read date and time
rr	Read logging rate
resetoff	Reset temperature offset to zero

t	Get Temperature reading
ta[i]	Auto temperature output to serial port (+ to enable, - to disable)
u[i]	Unit (c = °Celcius, f = °Fahrenheit)
wd:yyyy/mm/dd	Write current date
wt:hh:mm	Write current time (23:59)
wr[n]	Write logging rate
n	Logging rate
1, 2, 3, 4, 5	1, 2, 5, 10, 30 sec
6, 7, 8, 9	1, 5, 10, 30 min
10	1 hour
wtune[i]	Optimize CCD read time (wtune+ to enable, wtune- to disable)
y	Probe optical signal strength

6.4 Detailed description of USB serial commands

All commands must be terminated by a carriage return character (). When more than one argument is required, each argument must be separated from the next one by a blank or space character. Characters are not echoed back to your controlling device.

Every time a command is executed successfully by the thermometer, the “*” prompt character is automatically sent, except in case of failures when the “Errx” error code is sent instead. Do not send your next command before receiving either the “*” or the “Errx” prompt. The “[” and “]” characters must not be typed in; they are used here for ease of reading only.

“baud:nnnn” Making a change in the baud rate used to communicate with the serial port will automatically disable your serial port client program: you will then need to disconnect *HyperTerminal* or *Tera Term*, modify the setting on your serial client to match the setting you just saved, then reconnect. This command is useful if you need to transfer files faster: by raising the baud rate you will also make the file transfer faster. Remember that a baud rate change for the Neoptix protocol is not persistent after a reboot; it will revert to 9600 baud.

“batt?” This command gives information about the internal Lithium-Ion battery. The following information is given: battery voltage (mV), charging current (mA), capacity (mAh) and % charge availability.

“c:xxxx” The content of log files is designed to be easy to copy and paste into a Microsoft Excel spreadsheet. Certain older versions of Excel had a limitation of about 65,000 lines which could be copied and pasted into it. For this reason, when a log file reaches that size, it is archived and a new log file is started. This has the benefits of saving disk space as well as providing a relatively small log file containing the latest readings ready for download. Archived log files can also be downloaded, or they can be disposed of file-by-file using this command.

“f[j]” This command forces an actual temperature reading (j); any resulting offset will be applied to all future measurements for that channel. This is useful to compensate for small temperature deviations that may occur between sensors. A maximum offset of ± 5 °C is recommended; if it is required for you to force a larger offset, your thermometer probably requires a new factory calibration; consult your distributor or factory for more information. This command alters the internal calibration of the instrument. Always follow the recommended procedure, as given below.

Force temperature procedure:

- I. Apply a stable and known temperature to the sensor tip
- II. Check the display reading for abnormal deviation from the known temperature

- III. Send the “f” command followed by channel number, a blank character and the reference temperature value (example “f2 27.0 ”). Temperatures must be entered in units as specified by the “u” command
- IV. Wait a few seconds
- V. Confirm that the readings correspond to the known temperature.

Note: You can revert at any time to the factory calibration using the “f” command (ex: “f ”).

Note: Always make sure you are reading a valid temperature value before using the “f” command; otherwise, your thermometer may display a random value for a channel where the “f” command has been used.

“format” This command deletes the current as well as all archived log files. This preserves disk space but is not necessary in normal use, even after several years, unless the logging rate has been reduced substantially on the device for long periods of time.

“gskip[i]” This command is useful to eliminate annoying dropouts that can happen when using “weak” probes. The parameter “i” indicates the number of scans that the Nomad system will perform before actually indicating that it cannot read the probe on a specific channel. The range of i is from 0 to 9; a value of 0 indicates that the Nomad makes no attempt at removing dropouts. A value of 3 to 5 is recommended, especially for transformer applications. This command is active even when the sleep command is valid, but is limited to a timeout of 2 minutes.

“h” Displays a help menu screen (see above).

“i” Returns general information regarding the instrument, as well as some parameters that have been programmed previously in the thermometer (either by serial commands or via the touch screen):

Ex: Model:	Nomad-Touch
Serial:	NMT003B
Number of channels	1
Calibration type:	Neoptix probe
Internal Software:	V1.0
Factory Calibration:	15/03/04 (YY/MM/DD)
Unit	degrees C
Temperature offset:	0.0

“l” This lists the files that you can download using the “d” command. This would include the temperature log files, as well as some information file related to the smart protocols, and other system files, such as “status”. File size is also given, for download time estimation. See section 5.5 for information regarding log file name convention.

“logging[i]” Convenience to start (logging+) and to stop (logging-) temperature logging in internal memory. Logging must be disabled to activate the logging “snap” mode.

“n+[i]” “n+o” or “n+e” This command can be used to change the calibration type that is active at any given time. “n+o” should be used to enable the Nortech-Fibronic, Inc. calibration, while “n+e” should be used for Neoptix probes.

“rd” This will display the current system date and time in the format “yyyy/mm/dd hh:mm:ss” (these settings are configurable with two separate commands, *wd* for the date and *wt* for the time, with the exception of seconds which cannot be set).

“rr” This displays the interval in seconds currently set on the system for logging. This interval can be reduced all the way down to one second; however, if the logging rate is set to a number of seconds less than 60, the system will reset this value on reboot to 60 seconds.

“resetoff” Please refer to command “f”, described above. This will reset the offset on the optical channel.

"t" Returns the current temperature reading. "---." is displayed when no valid temperature is available. All temperatures are returned in °C or °F unit, as specified by the "u" command.

ex: "t" , with the Nomad-Touch thermometer, will return:

+24.3
*

The "t" command is also available in a special "ta" version, that can be useful for continuously and automatically monitoring all enabled channels. This special mode is recommended when automatically acquiring temperature readings with a suitable data-logging software, and can be activated by issuing the "ta+" command, or deactivated with the "ta-" command. Once activated, the following information is automatically sent when the temperature on a channel has been acquired:

"C:I;T: ±xxx.x "

where i is the channel number, and xxx.x is the temperature reading (signed number).

"u[i]" Set units of measurements to either Celsius (i=c) or Fahrenheit (i=f). Note that this unit selection is the same as the temperature unit selection made from the keypad (if the display option is installed).

Ex: "uc" , to select °C (Celsius).

"wd:yyyy/mm/dd" This will reset the system date of the Nomad to a provided valid value. This value will be used in system and temperature logs. The system date is persistent even after a prolonged power down of the device. To view the current system date, refer to the "rd" command.

"wt:hh:mm" This will reset the system clock of the Nomad to provided hour and minute values. The system time is persistent even after a prolonged power down of the device. To view the current system time, refer to the "rd" command.

"wr[n]" Write logging rate.

<i>n</i>	<i>Logging rate</i>
1,2,3,4,5	1,2,5,10,30 sec
6,7,8,9	1,5,10,30 min
10	1 hour

A logging rate less than once per minute is considered abnormal and is automatically reset to once per minute following a reboot. Log files can be listed with the "l" command and downloaded with the "d:xxxxx" command. Entering this command will also force implicitly the command "logging+". Entering the command "logging-" will force the "snap" mode to become active.

"wtune[i]" This command can be used to increase the optical integration time to force the Nomad system to read temperatures when the optical signal is weak, at the expense of a slower response (slower temperature update frequency). This command (wtune+) enables this feature. It should be noted that in general the scanning rate of the system would slow down when this command is enabled. It is highly recommended for power transformer applications.

"y" The "y" command can be used to confirm the signal strength of a probe and/or its connection. It can be used as a diagnostic tool to confirm the good operation of a probe and its extension cable (if applicable) connected to a channel. The returned value can be between 1.00 to approximately 3.00; a higher value is better. A minimum of 1.25 is required for a channel to return a temperature. A complete discussion on how to interpret the "y" command, refer to Section 6.5 below.

Ex: "y" , with the Nomad thermometer, will return:

CH1: 98%, ratio:2.01**, lamp: 200, CCD: 250 ms (auto*) +23.5

*: Value: Auto (when wtune+ is active) or Fixed (when the wtune command is disabled).

** : 1.0 to 1.1 indicates that no probe is detected for this channel.

6.5 Interpretation of “y” command results

The Neoptix Nomad-Touch systems are fitted with a function that gives an evaluation about probe signal strength or signal quality index; in Neoptix jargon, this is called the “y” command. The easiest method to access this command is to use Windows’ HyperTerminal or QLink. This information is also displayed on the main window of the Nomad-Touch color screen.

Typically, the “y” command will return the following information:

CH01: 100%, ratio:2.38, lamp:160, CCD: 100, (auto) +23.5

CH01 indicates the channel number (always 1 for a Nomad system)

2.05 indicates the power strength (ratio) and can span from about +0.3 to +2.8. You can interpret it approximately as follows:

- 0.3 to 1.07: no probe is detected
- 1.07 to 1.25: a probe is probably present, but exhibits a very weak signal; its reading is usually rejected, as it is considered as unreliable
- 1.25 to 2.7: a good probe is present (the higher the ratio the healthier the probe).

Lamp attenuation: gives an indication about the white light lamp intensity for this channel. It ranges from 250 (weak lamp) to 0 (strong or intense lamp). A weak lamp is usually preferred and indicates a “healthy” probe.

CCD time, in millisec: this is the CCD (charge couple device) optical integration time in millisecond; it can range from 50 to 500 ms. A weak probe will normally have a long integration time.

(auto) means that the wtune feature is enabled. If wtune is disabled, this information is not present.

To summarize, a very good probe is characterized by a good quality index ratio (>1.8), then by a high lamp attenuation (>150) and finally by a short integration time ($<200\text{ms}$). Also, dirty connectors will contribute to lower probe strength; always assure that all fiber connections are clean before evaluating probe performance.

This Nomad includes a convenient “Power%” feature that makes probe strength interpretation easier. The “Power%” is only available when the “wtune” feature is enabled. For additional information regarding the interpretation of this percentage parameter, especially when dealing with power transformer applications, whereby an OFT and an extension cable is used, please refer to the Neoptix Probe Installation Guide, part number g1009rxx; this guide is available from Neoptix.

Warning: These values are approximate and will change slightly from system to system.

Note: For transformer T2 probes, as they are normally going to be used with a feedthrough and an outside extension cable, it is recommended that a probe (when measured directly, without feedthrough) is to be considered healthy when its Power % reading is at 100% (probe alone, no feedthrough, no extension cable); with a feedthrough and extension cable, the minimum acceptable and recommended percent level is 65%. If the 1-meter short extension cable is used in addition, then these 2 values should be lowered by 10%, respectively to 90% and 55%.

6.6 Typical temperature reading sequence

Once all parameters have been set, the following sequence should normally be followed to extract temperature information from your Neoptix thermometer. 2 procedures can be used for this purpose. The first method consists in using the “ta” command (preferred), while the second sequence would be:

- a) The host computer should send the “t” command, followed by a  character.
- b) The thermometer responds by echoing the requested temperature values, as indicated above; the transmission is terminated by a “*” character.
- c) When the “*” character is received, it is suggested to immediately terminate the dialog session by having the host computer issue the “r” command followed by a  character.

7 ERROR CODES

The following error messages are displayed under certain error conditions:

RS-232	Display	Description
Err2	Err2	Internal memory checksum error. Memory corruption. Message "Corrupted Memory" will be displayed on LCD display. If this happens, use caution in reading temperatures, as these readings may be in error. Contact Neoptix.
"- . - ."*	"- - - -"	Temperature out of maximum instrument limits or no signal
Err5		Argument out of range
Err6		Unrecognized command

*: In case of anomalies, the following values are returned (USB serial interface):

-999.99: Temperature too high

-999.66: Temperature error (- - . - is displayed)

-999.55: Channel is disabled

-999.44: Internal error (slave timeout)

-999.33: Internal error (slave error)

-999.11: Temperature too low.

Note that these error codes are not applicable when using the QLink software package. These high-level software packages are programmed to automatically handle all types of errors, as outlined in the next section.

8 QLINK SOFTWARE DESCRIPTION

QLink is particularly interesting for users of the non-Ethernet versions of the *Nomad-Touch*, as it offers a friendlier procedure to load various parameters, such as relay and optical channel parameters that would otherwise require to be set by hand using the instrument 4-button keypad. The goals and purposes of this software package are as follows:

- Display temperature information, for up to 16 channels per instrument, for up to 4 instruments (maximum of 64 channels). This information can be seen in either digital or graphical forms. Data can be logged to a file, if desired.
- Acquired temperature information can be presented in graphical form.
- Data can be presented in punctual format, or with minimum, maximum and average (for a long sampling period).
- Initialize and manage *Nomad-Touch* optical channel and associated control parameters.
- Upload new *Nomad-Touch* firmware (software upgrade).
- Download data and event logging files from the *Nomad-Touch*, and other files.

QLink can simultaneously support up to 4 Neoptix T/Guard instruments, either through their serial COM ports. Currently, this tool supports the T/Guard-408, T/Guard-408XT, T/Guard-2B, *Nomad-Touch*, T/Guard-405 and T/Guard-Link-RevB.

QLink will connect to your *Noamd-Touch* through its USB port, which is effectively an emulation of a serial Com port. Before using QLink, you must insure that the software driver has been installed correctly; please refer to chapter 4 for more information.

QLink has been introduced to replace the older OptiLink-II software. All references to OptiLink-II has been removed from this user guide.

This guide shows screenshots that have been done mostly with a 408 instrument; your screen may look a little bit different if you are using another instrument model, but the philosophy of the program remains the same.

8.1 Installation and Initial Operation

To download QLink version 1.0 or above, click this link to download the latest version (no passwords required): http://neoptix.com/directdownload/DVD/Software_QLink/QLink-Setup.zip. Simply execute this application, and QLink will be installed on your PC. The QLink tool is installed using a standard Microsoft Windows setup.exe package. Double-click on setup.exe to launch and accept the usual Windows Security warning to proceed.

This release of QLink is compatible with Windows versions ranging from Vista to Windows 10 (XP is not supported). "InstallShield" will manage the installation procedure, and will install Microsoft .NET Framework version 4.0 or above if required. A PC reboot may be necessary. You may need administrator rights to install this software on your PC.

Very important: The current version of QLink will work correctly with the *Nomad-Touch* that has the firmware version the 3.0 or later. If your *Nomad-Touch* has an earlier version, you will get an information message with instructions on how to update your instrument; see section 8.4 for instructions on how to perform the firmware update. In case of questions, do not hesitate to contact Neoptix support team.


On the . Make sure your serial port parameters are correct and that your cable matches your port duplex settings! Neoptix protocol serial settings are baud 9600, Parity None and Stop bits 1.

Warning: To reinstall the software, or install a new version, it is mandatory to first uninstall the older version. This must be done by using the “Program and Features”, found in Windows Control Panel.

After installing all the required software, you can execute QLink. This window will appear. Normally, a scan of all “active” COM ports will automatically try to “find” compatible instruments; you can also click again “Scan” to perform a new COM port scan, or click “Connect” to connect to a specific COM port.




If you have one instrument connected to your PC, the following window will appear²:



To connect additional instruments, click “Connect”, and click on one COM button once you know the wiring and hardware for this COM port are correctly set up. For example, if 2 408 instruments have been connected to QLink, you will get this:

² If you get a message saying that your instrument firmware is not compatible with QLink, please refer to section 8.4. It may also be possible that you get this message even though your firmware is up-to-date; in this case, we suggest you cancel this window and try to connect again.



Once an instrument is connected, it will automatically save all temperature data in the PC memory; this data is saved every second (sampling rate is 1 second), for up to 72 hours; this data can be viewed either in graphical form. Note that temperature can be logged only if the logging process is explicitly started (data prior to starting the logging process cannot be saved to a logging file).

8.2 What is new in QLink

QLink is a replacement for OptiLink and OptiLink-II. QLink offers a number of improvements; here is an overview of the main changes:

- The Neoptix communication protocol has been completely revamped with the idea of making it much more robust, more resilient to communication errors.
- This new protocol has the implication that QLink will not work with old firmware versions; if you get a message stating that your instrument is not compatible with QLink, see upgrade instructions in section 8.4 below; contact Neoptix for additional instructions in case of problems.
- Parameters that would require HyperTerminal to be changed as they were not included in OptiLink-II can now all be changed using QLink.
- Temperature data is kept in the PC memory from the time an instrument is connected to the PC. Default acquisition interval is one second. Old data is kept in memory for a period of 72 hours. Any saved data can later be displayed on graphic form. Please note that old data cannot be saved later to a file; if you want to log temperature values to a file, you must open a file and logging will then start.
- The graphic tool has been completely changed.
- It is now possible to modify and even create a configuration file without having an actual instrument connected to your PC.


8.3 Overview of QLink

Here are some of the steps or tasks one will do in QLink on its first use:


- Make sure the instrument you want to connect is corrected wired to your PC, through its RS485 port. You can test your link with HyperTerminal or Tera Term. Click “Connect” to connect to this instrument, if not already connected.
- Click on “Temperatures” to see the Acquire Temperature window (Zone 3, as illustrated in the figure below).
- To configure your instrument, refer to Zone 2. Click on the instrument logo you want to configure, and the you can configure everything you want here, from relay settings to optical channel configuration. Do not forget to click “Save to Device”!

- To download files, such as temperature logs (internal to the instrument), or the status file, Click “Download” from the menu items available from **Zone 2**.

You can experiment with the other menu items, to explore the multiple functionalities that have been built-in in QLink. The remaining sections in this chapter present in more details these functionalities. This figure presents the main menu items available in QLink.

 The screenshot shows the QLink software interface. At the top are 'Scan' and 'Connect' buttons. Below is the 'Devices Config' section with a green status icon and the text 'COM16:T/Guard 408'. The 'Temperature' section features a large red digital display showing '88.8', a line graph labeled 'Temperatures', and a 'Graph' button. The 'Config Files' section is at the bottom with an 'Import Config File' button.	Zone 1 Scan and Connect: To connect instruments to QLink. Zone 2 Your connected instruments are listed here (up to 4). Click on one of the listed instruments to open the configuration windows. You can configure only one instrument at a time. Right click on an instrument, and select “Disconnect” to remove this instrument from QLink. Zone 3 This section allows to display, to graph and to log temperature data. You will be able to see simultaneously all data for all connected instruments. Zone 4 “● Logging” will be flashing when temperature data is being saved to a file. Zone 5 This section allows to generate and edit configuration files remotely, without having an instrument connected in real time to QLink. These files are stored in a predefined directory, that can be changed in the “Preference” window. Click a file to open its configuration window. This allows to import to the QLink directory any configuration that could be saved elsewhere in your PC.
---	---

To improve the user friendliness of QLink, a “Preference” page is available. This is illustrated here. Make sure you set your preferences, so QLink becomes easier to use. This page can only be accessed from QLink menu bar.



A help menu is also available.

8.4 Firmware Upgrade Procedure


When QLink tries to connect to a compatible instrument, it will check the compatibility that particular instrument. Depending on the particular model of instrument you have, you will be offered to perform the upgrade either via the Ethernet port or the serial port; if available, the upgrade via the Ethernet port would be preferred because the process would take much less time (about 10 minutes with the Ethernet port, or more than 3 hours with the RS485 port).

Please note that it is also possible to perform a firmware update as you wish using the update function built in QLink; see section 8.8 for more information.

8.4.1 Upgrade Procedure, with Serial Port

When QLink is started, and upon detection of a compatible instrument, QLink will confirm the compatibility of QLink and the firmware version currently running in the instrument. If both are found to be incompatible, QLink will propose to perform an update of the instrument firmware. QLink is always shipped with firmware files that can be used to upgrade your instrument; these are files with the extension *.s19.

When you get this window, click the “Serial” button, and the upgrade process will start by itself.




Warning: It is possible that you may get this message even though your instrument firmware is up-to-date. This is due to a known software bug, not resolved at this time. If this is the case, click the “Cancel” button, and try to connect again.

Warning: The best serial hardware configuration is full duplex (4 wires). Also, make sure the wiring between your computer and the instrument is short, less than 1 meter if possible.

Warning: The upgrade using the serial port will take up to 3 hours to perform, and should not be stopped. The downloaded file size is about 0.5 megabyte for the Nomad-Touch.

The following window shows in real time the download and upgrade status.




At the end of this upgrade process, it is strongly suggested to exit QLink and to restart it. Then, QLink should start normally.

This upgrade process uses the standard XModem file transfer protocol. To work correctly, it requires a good and reliable serial port link; many USB-RS485 converters have shown to have problems; Neoptix recommends converters with the brand name "B&B Electronics", see website <http://www.bb-elec.com/Products/USB-Connectivity/USB-to-Serial-Adapters/In-line-USB-to-Serial-Converters/USOPTL4.aspx>.


8.5 Acquire and Display Temperature Data

The "Acquire Temperatures" application will display up to 64 temperatures (16 temperatures for up to 4 instruments), as follows. Click on "Temperatures" (in **Zone 3**, as shown in the above figure, section 8.3).



The temperature for up to 64 channels can be shown in this window.


To see a graphic of the same data as it is being acquired, click on "Graph". You get the following window.



The graphic window will display a total of 200 to 300 temperature data points horizontally.


Various options are available when you are showing a graphic. Most are obvious, but some need some explanations:

- Curves can be shown in either “Punctual” mode, or Average and Min-Max modes. In Min-Max mode, the thickness of the curve will grow to show graphically the minimum and maximum temperatures observed within the sampling period.
- The parameter “Time Interval Scale” corresponds to the time interval between two time intervals on the time scale. This means that the total graph time is always 10 times the “Time Interval Scale”.
- As mentioned earlier in this chapter, the graphic can show data that has been acquired and saved in memory since the instrument was connected to QLink. This saved data is stored with a time resolution of 1 second, and for a period of up to 72 hours (that is about 260,000 data points). Please note that the average and min-max data points are always “calculated” from this saved historic data; so you are free to modify the display format as you wish, as the original saved data is always preserved (up to a duration of 72 hours of course).
- Graphical data can be saved to a file in two ways:
 - o “Save as Image”. This will save a bmp or jpg file. This is simply an image of what you see on your screen.
 - o “Export Graph”. This will save a data file. This is an Excel compatible file (csv or tem extension). One data point on the graph will generate one line in your spreadsheet.
- To know the value of any point in the graphic, simply click on that point with the cursor, and the following information will be displayed (the blue dot is shown only in punctual mode; in average or min-max modes, the area of the curves pointed by your cursor is colored in blue):



8.6 Logging Data to a File


To save temperature data to a file, click on “Logs” (in **Zone 3**, as shown in the above figure, section 8.3). You will get this:




In this initial window, the data is shown in tabular form, in either Punctual, Min-Max or Average modes. These 4 modes of displaying the data are explained here:

- Punctual. This is the temperature values that were sampled at the beginning of each sampling period
- Min-Max. These are the minimum and maximum values of observed temperature during the sampling period. The raw data is sampled every second, which means for example that a requested interval of 1 minute will use 60 values to evaluate the minimum and maximum temperatures for that interval of 1 minute.
- Average. This is the average temperature observed during the requested interval. As for the minimum and maximum values, this average is calculated based on raw data sampled every second.

To save data to a file, you must first specify a file where the data will be saved. Click on “Start Saving Log to File”, and enter or select a file name of your choice. Available file formats are .csv and .tem; both are compatible with Excel; “.tem” is a tab delimited file where numbers are saved as xxx.xx; “.csv” is similar but uses Windows regional setting for number formatting; the extension “.tem” is the Neoptix standard. Click “Save”.




From this moment, new data will be saved to that file. Please note that old data acquired prior to specifying a log file cannot be saved to a file. During logging, two **red dots** will flash, confirming the logging operation. This is shown here.



8.7 Configuration Tool

QLink allows for configuring an instrument simply and quickly. To access the configuration pages, click on an instrument icon, as highlighted in this figure:



The information given in this page (General tab) are mostly informative. However, the following settings can be done:


- Date, time zone and time can be set.
- You can give a name to your instrument configuration, which can be saved on your hard disk. This file can be later open and edited, and then uploaded to this instrument or another compatible instrument (of similar type).

The 2 buttons at the top right of this window allow you to either save your modifications to the connected instrument, or to a file (extension .cfg). Saving a configuration to a file would be very useful for eventual transfer of that file to another instrument, to duplicate the same configuration, so these instruments have the same configuration. See section 8.8 for more information.

For the Nomad-Touch instrument, there is an additional configuration item: Snap Prefixes. Information about these prefixes is given elsewhere in this guide.


8.7.1 Configuration of Snaplog Prefixes

For Nomad users, QLink allows you to configure up to 10 prefixes which could be later user when saving temperature information using the snap tool. This is illustrated here:



8.7.2 Optical Channel Setting

Click on the “Channels” tab to access the page where you can set names, offsets and analog output parameters. This is shown here:



8.7.3 Offline Configuration Tool

With QLink, it is possible to generate configuration files for any compatible instruments, even if none are physically connected to your PC. For this purpose, QLink comes with default (with parameters set to their factory defaults) configuration files that you can use to build a configuration for your unconnected or future instrument. One such file is provided for each type of instrument (408, 408XT, 405, T/Guard-Link-RevB, Nomad-Touch and OEM board). Any of these default files can be loaded in QLink; see “Zone 5” in Section 8.3. These default files are read-only, and thus must be saved under a different name (the “Save” button cannot be used; you must save your modified file to a new file. Once your instrument is later connected to your PC, you will be able to upload this new configuration file to that instrument.


Warning: When uploading a new configuration file, you need to realize that all parameters then present in that instrument will be overwritten.

8.7.4 Download Files Tool

This tool can be very useful to download these types of file:

- Status.txt: This is the status file described elsewhere in this document. It essentially gives an overview of all parameters of your system, that can easily be e-mailed or printed.
- Temperatures.tem: This is the current logging file for temperature information. When this files reaches 65,000 lines long, it will be archived using the current date and time as a prefix to generate temperatures.tem file name, and a new temperatures.com file will open.
- Event.log: This is the same as the temperatures.com files, but for event information (alarms).
- Logging files, both for temperatures and for events; these files are best read with Excel. These files are limited to a total length of 65,000 lines.
- Smart protocol related files, for Modbus (modbuspt.txt), DNP3 (dnp3pt.txt), IEC 60870-5 (60870pt.txt) and IEC 61850 (*.cid and *.icd); these files are text files, and can be read easily with Notepad or WordPad. These files will appear in the list only if the corresponding protocols are active.
-

The download tool is shown here:



By default, the files are saved in the directory "...My Documents\QLink\Download"; you can change this as you wish. When you download a file, its name is fixed. If you download the same file multiple times, the file name is appended with "(1)", "(2)", etc. Downloading large files can take some time... the download rate is approximately 5 kilobytes per second.

Take note that this tool cannot be used to download an instrument configuration file; a configuration file should be saved to file using the procedure given in section 8.7.

The log files (temperature and event) can be deleted, by clicking the Delete button. Read-only files cannot be deleted.


Warning: The download tool includes safeguards to trap communication errors. If there is an error that is detected, the file name will be appended with the word “_ERROR”; if this happens, you can still use the file, but exercise caution regarding the validity of its content. In any case, please send the displayed error information to Neoptix (support@neoptix.com) to allow us to improve future versions of QLink.

8.8 Upload files Tool


This tool is useful to transfer an instrument configuration file that was previously saved in your PC to the instrument now connected to QLink.

The configuration file that could be uploaded should have been generated from an existing instrument, as described in section 8.7. It is also possible to upload a configuration file that could have been modified offline, see section 8.10.

Any configuration upload should be done with great care, as all parameters in the connected instrument will be replaced by the ones included in the file that you will upload. Once uploaded, there is no coming back!




Click “Apply Configuration” to upload this configuration to the connected instrument. The following window will appear, where you can select the type of parameters that will be uploaded. Click “Apply” to proceed and “Yes” to the confirmation window.



From this tool, you can also perform a firmware update of your choice. If you have received a “.s19” file, you can perform the upgrade here. The tool allows you to perform the upgrade using the RS485 serial port. The upgrade procedure is described in details in section 8.4 above.


8.9 Signal Quality Information

This window is useful to display the “health” status of the optical probes connected to your instrument. This is shown here. The information presented in this page is given to help you “debug” your probes; the information is updated in real-time.



8.10 Working on Configuration Files, with no Live Instrument

With QLink, it is possible to create or modify a configuration with no instrument connected to your PC (offline).



The best way to create a new configuration file is to first connect QLink to an instrument, and save its configuration to a file, such as "neoptix.cfg"; see section 8.7 for instructions on how to do this. Click on this file name "neoptix.cfg", as illustrated above in the red circle. Then all parameters that are available for this configuration file are given in the main pane of this window; see section 8.7 above for specific details on how to work a configuration. Once you are done with your configuration, you can either save it to the same file, or save it to a new configuration file (if you click "Save as New Config File").

In order to be able to work on an existing configuration file, you must first import it to the directory where QLink normally stores this type of files, normally "My Documents\Qlink\Config_Files". These import operations can be done by clicking "Import Config File", found at the bottom left of the main window. It is possible to change this target directory from the "Preference" window (select "Option" and then "Preference" from the menu bar).

8.11 Troubleshooting

Here are some tricks you can try to fix any problems you may have with QLink, especially when starting the program:

- 1- Make sure the FTDI serial protocol software driver is installed correctly. See this website for more help: http://www.ftdichip.com/Support/Documents/AppNotes/AN_119_FTDI_Drivers_Installation_Guide_for_Windows7.pdf
- 2- Make sure the serial protocol on the is set to "Neoptix".
- 3- Make sure the COM port is listed correctly in the Windows Device Manager. Check the port properties.
- 4- When trying to connect to an instrument, and if you get a message saying that you should upgrade the instrument firmware and you know very well that your firmware is up-to-date, then you should cancel the process, and try to connect again.
- 5- Try connecting to the port with a HyperTerminal client (or Tera Term) to see if it is responsive.
- 6- This version of QLink requires that the firmware version be 3.0 or above. If your firmware is older, consider upgrading it. Some functions could crash QLink if you try to use it with an older firmware version.
- 7- Try rebooting Windows.
- 8- Try re-installing your USB to serial port drivers on Windows.
- 9- When reinstalling QLink, you must first manually uninstall the current version; this can be done through the Programs and Features facility in Control Panel of Windows.

8.11.1 An example of status file

Here is an example of a typical status file. The content of this file gives an instantaneous "picture" of your Nomad-Touch system. When contacting Neoptix for support, try to email a copy of this file with your request.

Nomad Touch - Status Report
2015/03/23 08:32:51

Serial Number: NMT003B
Firmware version: 0.07

Hardware code: 1
Calibration date: 15/3/20
Up time: 0 day, 0 hour, 20 minutes, 26 seconds

----- Serial Interface -----

Baud rate: 9600
Parity: None
Stop bits: 2

----- Temperature Data Logging -----

Logging Enabled: yes
Logging rate: 120 seconds

List of files:

>temperatures.tem (446.304 KB)
Total: 1 files, 446.304 KB

----- Acquisition -----

Wtune: ON
Gskip: 5
Calibration type: Neoptix probe
Unit: Celsius

----- Offset Setting -----

0.0

----- Signal Quality -----

CH01: 100, ratio:2.35, lamp:160, CCD:100ms (auto) 22.21 C

Snap Log Prefix Name List :

Probe (active)

Channel

Transformer

Winding

Measurement

User01

User02

User03

User04

User05

User06

User07

User08

User09

User10

List end#

*

(Status Report end)


9 USING TEMPERATURE PROBES

9.1 Caution

Each time you connect a temperature probe to the unit, the probe **optical connector should be cleaned beforehand**. Otherwise, particles of grease or dirt may obstruct the device internal connector and affect the measurements by completely blocking the signal or by generating too much attenuation when using a long fiber length.

Never use a cloth other than the type recommended for fiber optic cleaning. Dampening the cloth with pure isopropyl alcohol ensures good cleaning.


Occasionally, clean the inside of the bulkhead connector (attached to the thermometer) with a wipe or cotton swab dipped in alcohol (2.5 mm mini foam swabs work best).



For very dirty connectors, acetone can also be used, but should be used very carefully, as it is a very strong solvent. Care should be exercised so you do not apply any on plastic materials, etc.

9.2 Description

The optical connector used is a standard ST type connector.



To install the connector,
Slide the ferrule key gently into the above key.
Then, turning, insert the two BNC pins into
The appropriate slots on the ST connector.

9.3 Warning

The T1 probe is quite fragile and it must be handled carefully. Please note that any probe damages are not covered by the standard warranty.

Contact your distributor for additional chemical compatibility information.

Do not expose your probes to temperatures that are higher than specified. Permanent damage can be caused to probes that have been exposed to temperatures that are higher than their limits.

9.4 Working with cryogenic probes

The use of a cryogenic probe required special attention. In particular, the probes become more brittle at very low temperatures. Avoid cycling the probes quickly between cryogenic temp and ambient temperatures, as this may cause material fatigue at the probe tips.

Warning

Always wear protective gloves and clothing when working with cryogenic material.

Never use general purpose probes at cryogenic temperatures. Neoptix sells special probes that can be used at cryogenic temperatures.

Please note that your Nomad thermometer will require a special factory calibration to be used at cryogenic temperatures (below -80°C). Consult Neoptix for more information.

10 INDEX

Acquisition menu	17	Global temperature display	31
Agreement, warranty	4	gskip command description	22
Analog outputs		Hardware reference	15
How to set in QLink	35	Help menu	
Calibration		On-screen menu	16
Annual re-calibration	10	HyperTerminal	
NIST traceable	10	How to use	19
Periodicity recommendation	10	Win7 and Vista users, HyperTerminal Private Edition	19
Requirements and description	10	Illustration	
Calibration statement	10	Extension cable	10
CCD integration time verification	24	Nomad-Touch outline	12
Charging time, batteries	14	Transformer T2 probe	10
Clearing offsets	22	Installation	
Client programs		Performance verification, probes	24
QLink	26	QLink	26
Configuration file		Internal batteries, charging time	14
How to generate offline with QLink	35	Internal battery description	14
How to save to a file, using QLink	34	Log download or delete page	
How to upload to a new instrument	37	Using QLink	36
Working offline, with QLink	38	Logging	
Connector, how to clean	41	File name convention	18
Coupling, ST-ST	10	Log viewer	18
Cryogenic probes	42	Menu	17
Date		Synchronization time, with NTP server	34
How to set time zone in QLink	34	Making your first measurements	12
Delete log file		Mating sleeve, ST-ST	10
Using QLink	37	Mechanical dimensions	12
Deleting temperature log files	16	Modifying a configuration file, offline	38
Disabling/Enabling snap mode	23	NIST traceable calibration	10
Display, touch screen technology	15	Nomad display, splash display	14
Download or delete page, data logging		Nomad hardware reference	15
Using QLink	36	Nomad screen	
Downloading files		Acquisition menu	17
Error messages in QLink	37	Display description	15
Global configuration file	36	Log viewer	18
Status file	36	Logging menu	17
System files	36	Setup menu	16
Driver software, for USB	12	Touch screen technology	15
Enabling/Disabling snap mode	23	Nomad-Touch description	8
Error codes	25	Nomad-Touch, specifications	9
Extension cable description	10	NTP servers, for time synchronization	
Factory default parameter reset	16	Using QLink	34
Factory instrument information	22	Offline configuration files	35
Fiber optic probe care	3	Optical channel setting	
File name convention, logging	18	Using QLink	35
Firmware		OptiLink-II software	See QLink software
Upgrading using QLink	30, 38	Options	11
First measurements, how to	12	Probe and accessory description	9
Front panel description, Nomad-Touch	12	Overview of QLink	28
FTDI USB driver installation	12	Parameter reset, to factory default	16
FTDI USB serial driver	39	Part 15 of the FCC rules	3
Global configuration file	34		

Patch cords	<i>See Extension cables</i>	ST coupling or mating	10
Performance verification, probes	24	ST probe connector	18
Power supply, for USB interface	11	Start guide, quick introduction	12
Prefix name, for snap mode	18	Status file example	39
Prefix names, how to select from LCD display	18	Status information file	
Probe		Download using QLink	36
How to work with cryogenic probes	42	ST-ST mating sleeve or coupling	10
Probe and accessory description	9	T1 probe description	9
Probe connector, ST	18, 41	T2, Transformer probe	10
Probe installation guide, g1009	10	Temperature display	
Probes		Punctual, min, max or average format	33
Measuring optical signal strength, with QLink	38	Temperature log files, how to delete	16
Performance verification	24	Temperature reading, how to automate	24
Testing, using y command	24	Tera Term software, how to use	19
QLink software package	26	Time	
Com port selection	27	Setting in QLink	34
Configuration tool	33	Time zone	
Deleting temperature log file from screen	16	Setting up in QLink	34
Firmware upgrade procedure	30, 38	Touch screen operation	15
How to connect multiple instruments	27	Acquisition menu	17
Overview of QLink	28	Log viewer	18
Preference window	29	Logging menu	17
Replacement for OptiLink-II	26	Power menu	16
Serial link wiring recommendations	26	Setup menu	16
Snap prefix entry	34	Transformer application documentation	10
Troubleshooting	39	Transformer probe T2	10
Viewing temperature data	31	Troubleshooting	
What's new in QLink	28	QLink	39
QLinksoftware package		Unit selection, C or F	23
Offline configuration	35	Unpacking your Nomad-Touch	11
Quick introduction	12	Upload file	<i>See downloading file</i>
Real-time clock		Using QLink	37
NTP servers	34	USB communication description	19
Return authorization number, RMA	7, 11	USB interface	
RS-485 interface		Communication description	19
Wiring recommendations for QLink	26	Troubleshooting USB driver	39
Serial command description	21	Where to find the driver file	12
Setup menu	16	USB power supply module, 1 A	11
Signal strength		USB serial commands	21
How to get using QLink?	38	Using temperature probes	41
Snap default prefix name	18	Warranty	
Snap log parameters	18	Agreement	7
Snap prefix entry	34	Limitations on probes and extension cables	7
Software		Warranty statement	4
QLink	26	Win7 and Vista users	
QLink replacement for OptiLink-II	26	HyperTerminal Private Edition	19
Serial communication description	19	Windows Device Manager	39
Serial communication protocol	19	Working offline, configuration file	38
Tera-Term, serial communication	19	Write logging rate	
USB driver installation	12	Setting up using QLink	34
Software upgrade statement	5	wtune command description, on serial port	23
Specifications, Nomad-Touch	9	y command description	24
ST connector, how to clean	41		

